

-

-

"10-YARD FIGHT"™ TABLE OF CONTENTS

1.	A. GAME FEATURES B. INTRODUCTION C. GAME INSTALLATION D. DIP SWITCH AND VOLUME CONTROL SETTINGS 1-3
2. N	A. CLEANING
	B. FUSE REPLACMENT
	C. VIDEO MONITOR REMOVAL
	D. PRE GAME INSTALLATION
	E. COVERGLASS REMOVAL 4
	F. PRINTED CIRCUIT BOARD REPLACEMENT
3. 1	DIAGNOSTIC PROCEDURE5-6
4. 11	LLUSTRATION & PARTS LISTS
	FIGURE 7 INCANDESCENT PANEL
	FIGURE 8 8-WAY JOYSTICK
	FIGURE 9 CONTROL PANEL
	FIGURE 10 DOOR ASSEMBLY SJC-3
	FIGURE 11 COIN DOOR
	FIGURE 12 COIN DOOR
	FIGURE 14 CABINET ASSEMBLY REAR VIEW
	FIGURE 15 CABINET ASSEMBLY FRONT VIEW
	FIGURE 16 POWER SUPPLY COMPONENT LAYOUT 21-23
	FIGURE 17 POWER SUPPLY SCHEMATIC 1 of 1 24
	FIGURE 18 FILTER BOARD 29
	FIGURE 19 TOP PCB (M52-Sound) 20
	FIGURE 20 TOP PCB (M52-Sound G) 2
	FIGURE 21 TOP PCB (M58-A-A) 28
	FIGURE 22 CENTER PCB (M58-A-A) 4 BOARD SYSTEM 29-33
	FIGURE 23 BOTTOM PCB (M58-B-A)
	FIGURE 24 BOTTOM PCB (M58-B-A) 5 BOARD SYSTEM 34-38

5. WIRING DIAGRAM FOLDOUT

"10-YARD FIGHT"™ UPRIGHT

1. GAME SET-UP

A. GAME FEATURES

TAITO AMERICA CORPORATION'S "10-YARD FIGHT"™ upright game is housed in a compact and highly serviceable cabinet with many added features.

A larger designed cash box has been incorporated into the design of this cabinet.

By putting wheels on the cabinet, moving the game from one location to another is made much easier.

The Control Panel has a polycarbonate overlay, so cigarette marks and mars can easily be wiped clean. This overlay can be replaced if necessary.

The Marquee and Coverglass are made of fully Tempered Glass to minimize breakage.

The Back Service Door houses all the P.C. Boards for the system making servicing of the game, if needed, much easier.

Lighted instructions are provided to further enhance the game and attract players, by making the instructions easier to read.

B. INTRODUCTION

"10-YARD FIGHT™" is a fast moving football game licensed by Irem Corporation exclusively to Taito America Corporation. "10-YARD FIGHT™" can be played by one or two players.

"10-YARD FIGHT"" lets all the armchair quarterbacks take the field, take the ball and take as much action as they can handle. The player must score a touchdown in the time allotted to go from high school and college ball all the way to the Pros and the Super Bowl with cheerleaders marking his progress in-between. Each level begins with the player carrying the ball on the kick-off as far up the field as he can before being tackled. Then he's in control as quarterback, running with the ball or throwing a forward pass to or lateral to a receiver who lets him know he's open by waving his arms. An intercept pass means a 20 yard penalty, points after can be scored by kicking the ball or running with it into the end zone and the clock is stopped when the player runs out of bounds.

"10-YARD FIGHT™" has a continuous play feature whereby the player can continue to play where he left off by inserting an additional coin.

So be the next All American Footbal Hero - Play "10-YARD FIGHT". Good Luck!

C. GAME INSTALLATION

TAITO AMERICA CORPORATION'S "10-YARD FIGHT" upright game is shipped ready for operation, but a last visual check should be made to insure the game is in good condition. Please verify the following before turning the game on.

Check the exterior of the game for shipping damage, chips, dents, or broken parts.

- * Open the Rear Service Door and check for any interior damage.
- * Make sure there isn't any damage to the wiring.
- * Check the Printed Circuit Boards, making sure there is no damage to the components.
- * Check fuses to make sure they are firmly in their holders.
- * Check for loose foreign objects, especially metal objects which may cause electrical problems.
- * Check Plug-in Connectors making sure they are firmly in their sockets.

* Check Switches making sure they are not damaged.

The Video Monitor is properly adjusted before shipping. If there are any adjustments necessary, refer to our Video Monitor Manual (72-00025-001). This manual contains all the manufacturers recommendations for adjusting the video monitor.

POWER REQUIREMENTS

TAITO AMERICA CORPORATION'S "10-YARD FIGHT" upright game is shipped ready for operation at 120VAC, 60Hz with a power consumption of approximately 250 Watts.

CAUTION

For safe operation it is recommended the cabinet be grounded. This game is equipped with a three conductor power cable. The third conductor is the ground conductor and when the cable is plugged into an appropriate receptacle the game is grounded. The offset pin on the power cable's three-prong connector is the ground connection.

LOCATION SPACE


Depth 35" (87.5cm) Width 24" (61cm) Height 68" (171cm) Weight 300 lbs. (Packaged Weight)

D. DIP SWITCH AND VOLUME CONTROL SETTINGS

DIP SWITCHES

TAITO AMERICA CORPORATION'S "10-YARD FIGHT" game provides the following option switches. See Figure 1. These option switches can be found on the Game Board (99-AA017808).

FIGURE 1



"10-YARD FIGHT" DIP SWITCH ADJUSTMENTS

DIP SWITCH 1

0	PTIONS		SWITCHES	1	2	3	4	5	6	7	8
T	IMER		NORMAL			OFF	OFF				
_	PEED	Ī	X 1.3			ON	OFF				
-	ETWEEN	Ī	X 1.5			OFF	ON				
P	LAYS		X 1.8			ON	ON				
		COIN- SELECTOR	1 COIN/1 PLAY					OFF	OFF]	
	MODE 2	E Z	2 COINS/1 PLAY					ON	OFF		
] d	3 COINS/1 PLAY					OFF	ON		
	DIP SWITCH 2 POSITION 3	D	FREE PLAY					ON	ON		
	ON	COIN- SELECTOR	1 COIN/2 PLAYS							OFF	OFF
		E Z	1 COIN/3 PLAYS							ON	OFF
		105	1 COIN/5 PLAYS							OFF	ON
		8	1 COIN/6 PLAYS		AL- WAYS					ON	ON
COIN MODE (SEE		1 COIN/1 PLAY				OFF	OFF	OFF	OFF		
Z			2 COINS/1 PLAY		OFF			ON	OFF	OFF	OFF
	MODE 1		3 COINS/1 PLAY					OFF	ON	OFF	OFF
(S	DIP SWITCH 2		4 COINS/1 PLAY					ON	ON	OFF	OFF
EE	POSTION 3		5 COINS/1 PLAY					OFF	OFF	ON	OFF
NOTE)	OFF		6 COINS/1 PLAY					ON	OFF	ON	OFF
E			1 COIN/2 PLAYS					OFF	OFF	OFF	ON
			1 COIN/3 PLAYS					ON	OFF	OFF	ON
			1 COIN/4 PLAYS					OFF	ON	OFF	ON
			1 COIN/5 PLAYS					ON	ON	OFF	ON
			1 COIN/6 PLAYS					OFF	OFF	ON	ON
			FREE PLAY					ON	ON	ON	ON
	CONTINUED PL	AY	YES	ON			•				
		.,	NO	OFF							

Note!

Set for Coin Mode 1 in case a single coin-selector or two selectors of the same coin value are used. Set for Coin Mode 2 in case two coin-selectors of different coin values are used.


DIP SWITCH 2


OPTIONS		SWITCHES	1	2	3	4	5	6	7	8
SCREEN INVERSION	PLAYER 2		OFF							
SCREEN INVERSION	PLAYER 1		ON							
CABINET TYPE	TT			OFF]				
ONDINETTILE	UPRIGHT			ON]				
COIN MODE	MODE 1				OFF	AL-		AL-		
CONT MODE	MODE 2				ON	WAYS		WAYS		
FREEZE PICTURE	NORMAL					OFF	OFF	OFF		
FREEZE PICTURE	FREEZE]	ON	OFF		
HIT MODE	NORMAL								OFF	
	NO HIT								ON	
TEST MODE	NORMAL									OFF
	TEST									ON

NOTE! Press 2P. start button to freeze picture. Press 1P. start button to let it move again.

VOLUME CONTROL SETTING

The Volume increases by turning the potentiometer as indicated in Figure 2.





POWER ON/OFF SWITCH

The power on/off switch is located in the front lower left hand corner of the cabinet.

2. MAINTENANCE

All games require a certain amount of maintenance to keep them in good condition. A periodic check of mechanical controls would be benefical to guarantee your game will be profitable.


A. CLEANING

The exterior of the game, all metal parts and all plastic parts can be cleaned with an non-abrasive cleanser. Caution should be used when cleaning the plastic, a dry cloth can cause scratches and result in a foggy appearance.

B. FUSE REPLACEMENT

This game contains 8 fuses. Seven of these fuses can be found on the Power Supply Assembly, five (5) are on the PCB and two (2) are on the Power Supply Bracket. One (1) is located at the bracket where the AC line cord comes into the cabinet. See Figure 3 for location of these fuses.

FUSE REPLACEMENT FIGURE 3



C. VIDEO MONITOR REMOVAL

If you need to remove the Video Monitor follow the instructions listed below:

NOTICE:


"This equipment complies with the requirements of Part 15 of FCC Rules for a Class A computing Device. Operation of this equipment in a residential area may cause unacceptable interference to radio and T.V. reception requiring the operator to take whatever steps are necessary to correct the interference."

- * Turn game power switch off.
- * Disconnet the power from the line voltage.
- * Make sure back door is open fully.
- * Disconnect the Monitor cable connector.
- * While holding the monitor bracket take out the two rear side bolts, one on each side of the cabinet.
- * Carefully lower the monitor on to monitor stops.
- * Remove the four mounting bolts and disconnect the braided ground wire.
- * Slide the monitor out by pulling the monitor toward you.

CAUTION

Use extreme caution and do not touch electrical parts of the Monitor Yoke area with your hands or with any metal object in your hands! High voltages may exist in any Monitor, even with power disconnected.

MONITOR REMOVAL FIGURE 4



D. PRE GAME INSTALLATION

The following precautions should be followed when installing the game.

- * Avoid rough handling of the game, the picture tube is fragile.
- * Install the game on a level surface.
- * Avoid installing the game where it may receive excessive sunlight or heat, to protect the game from rising internal temperatures
- * Do not install in a damp or dusty location.
- * For a short time after connecting the power to the game, the picture may be temporarily distorted.

The monitor's purity is affected by the earth's magnetic tield, causing a variation of color. By turning the game on for 10 to 15 seconds and then off for 20 to 30 minutes, the automatic degaussing circuit applies a degaussing field to the edges of the monitor. Doing this several times will correct the problem. Another way to correct this problem is to purchase a degaussing coil or bulk tape eraser at any Electronics store. This will help to immediately demagnetize the Video tube. Caution must be used with a degaussing coil so the magnetic field of the degaussing coil is not allowed to become too intense at any one place on the picture tube thereby causing a localized color distortion. If you move the game to another location after degaussing the problem may reappear. Refer to Monitor Manual.


E. COVERGLASS REMOVAL

To remove the Coverglass follow the Instructions listed below:

- 1. Remove the control panel by reaching up through the Coin Door and unlatching the latching clamps.
- 2. Disconnect the Control Panel Cable.
- 3. Lift the Control Panel out. The Coverglass can now be easily removed from the front of the game with no screws. To replace the coverglass simply reverse the above procedure.

NOTE: Be sure you are holding the glass firmly to ensure against any chipping or breakage.

FIGURE 5




F. PRINTED CIRCUIT BOARD REPLACEMENT

You may wish to remove the "10-YARD FIGHT"™ Printed Circuit Boards for servicing. Refer to Figure 6. The 10 Yard Fight Printed Circuit Boards are located on the inside of the rear Service Door for easy access. To remove the boards the following steps should be followed:

- Open the rear service door, the power will automatically be removed by the Interlock Switch located on the inside of the door frame.
- 2. Disconnect the connectors G, H and T from the boards.
- 3. Loosen and turn the Stop Bracket and slide the boards out of the board guides.

PRINTED CIRCUIT BOARD REPLACEMENT FIGURE 6



3. Test Mode

The Diagnostic program is activated by turning switch 8 of Dip Switch 2 to the ON position and turning the power switch ON. This diagnostic program is composed of 8 independent tests, the first two (RAM test and ROM test) of which initiate automatically as the power switch is turned ON. After these two tests end, the video monitor will display a list of the next six tests as described below when the 2-Player button is pressed:

- 01 DIP SWITCH
- 02 I-0 PORT
- 03 SOUNDS
- 04 CHARACTER
- 05 COLOR
- 06 CROSS HATCH PATTERN

Move the joystick to position the cursor at the desired test and press the 1-Player button to start the test.

To return to test list: Press the 2-Player button (except when 02 I—O PORT test ends). As 02 I—O PORT test ends, move the joystick left (the 1-Player joystick for table type game) while pressing the 2-Player button.

When all the necessary testing is complete, turn power switch OFF and turn switch 8 of Dip Switch 2 to the OFF position.

A. RAM TEST

If RAM is OK, "RAM OK" appears on the video monitor.

If RAM is at fault: "RAM NG XXXX YY ZZ"

XXXX RAM ADDRESS

YY RAM input data

ZZ RAM output data key

Press the 1-player button to continue RAM TEST or

Press the 2-Player button to end this test and advance to ROM TEST.

B. ROM TEST

If the ROMs are OK, the following appears on the video monitor.

RAM OK ROM 0 OK ROM 1 OK ROM 2 OK ROM 3 OK

If any of the ROMs are at fault, for instance, ROM 1, the following appears on the video monitor.

RAM OK ROM 0 OK ROM 1 NG ROM 2 OK ROM 3 OK

ROM LOCATION TABLE

MEMORY	LOCATION TABLE
#	LOCATION
RAM	3J
ROM 0	3R
ROM 1	3N
ROM 2	3M
ROM 3	3К

C. DIP SWITCH TEST

When the video monitor displays the test list, control the joystick to position the cursor at 01 and press the 1-Player button.

This test shows the state of switches of Dip Switch 1 and 2 and the results of game adjustments.

1 = ON

0 = OFF

DIP	SW	1	2	3	4	5	6	7	8	
	DSW 1	0	0	0	0	0	0	0	0	
	DSW 2	0	0	0	0	0	0	0	1	
Т	IME REDUC	ED B	Y DEAD	BALL	Ņ	ORMA	L			
C	OIN MODE									
s	ELECTOR A		1 CO	IN 1 P	LAY					
S	ELECTOR B		1 CO	IN 2 P	LAYS					
C	ABINET TYP	Έ	ι	JPRIG	HT					

D. I-O PORT TEST

While the video monitor displays the test list, control the joystick to position the cursor at 02 and press the 1-Player button.

This test checks if all the switches on the Control Panel and Coin Doors are working correctly. The following display appears.

1 = 0N

0 = OFF

	1	2	3	4	5	6	7	8
KEY 0	0	0	0	0	0	0	0	0
KEY 1	0	0	0	0	0	0	0	0
KEY 2	0	0	0	0	0	0	0	0

*TIMING 0000

*TIMING starts at 0000 and adds one count approximately every second

KEY	0-1 1-Player Button
	0-2 2-Player Button
	0-3 Service Switch
	0-4 Coin Switch A
KEY	1-1 P1 Joystick right
	1-2 P1 Joystick left
	1-3 P1 Joystick down
	1-4 P1 Joystick up
	1-6 P1 Forward Pass Button
	1-8 P1 Sideways Pass Button
KEY	2-1 P2 Joystick right
	2-2 P2 Joystick left
	2-3 P2 Joystick down
	2-4 P2 Joystick up
	2-5**Coin Switch B
	2-6 P2 Forward Pass
	2-8 P2 Sideways Pass
	2 0 2 oldenayor dee

**Coin Switch B is for coin doors with two coin selectors of different values.

P2 Switches are for cocktail table games only.

To terminate this test and bring the test list back to the video monitor, move the joystick left while deprressing the 2-Player button.

E. SOUND TEST

While the video monitor displays the test list, control the joystick to position the cursor at 03 and press the 1-Player button.

A table of sound appears on the video monitor.

 01	BALL KICKING SOUND
02	LINEMAN BLOCKING SOUND
03	BLOCKING SOUND
04	TACKLING SOUND
05	GAME OVER SOUND
06	CHEER 1
07	CHEER 2
08	QUARTERBACK CALL 1
09	QUARTERBACK CALL 2
10	REFEREE CALL 1
11	REFEREE CALL 2
12	JUMP TACKLE VOICE
13	WHISTLE SOUND
14	TIME OVER INSERT COIN
15	SNAPBACK SOUND
16	BALL PASSING SOUND
17	OPENING MUSIC
18	GAME OVER MUSIC
19	BALL CARRIER RUNNING
20	CHEERLEADER MUSIC
21	TOUCHDOWN MUSIC

Select a sound by positioning the cursor with the joystick. Depressing the 1-Player button repeats the sound.

F. CHARACTER TEST

While the video monitor diplays the test list, control the joystick to position the cursor at 04 and press the 1-Player button.

The video monitor displays four players carrying the ball which are flipped vertically and horizontally as shown below.









G. COLOR TEST


While the video monitor displays the test list, control the joystick to position the cursor at 05 and press the 1-Player button.

This test is comprised of five independent checkups. Pressing the 1-Player brings each checkup to the video monitor.

(1) A row of letters A thru Z appears along with a row of numbers 0 thru 9 as shown below.

ABCDEFGHIJKLMNOPQRSTUVWXYZ 0123456789

- (2) Blue field is displayed.
- (3) Red field is displayed.
- (4) Green field is displayed.




(5) Color pattern appears on the video monitor as shown above.

H. CROSS HATCH PATTERN TEST


Control the joystick to position the cursor at 06 and press the 1-Player button.

A cross hatch pattern is displayed as shown below.



INCANDESCENT PANEL FIGURE 7


ITEM	TAITO PART NO.	OESCRIPTION
1	27-00006-001	LAMP #47
2	26B00009-001	BAYONET BASE SOCKET
3	61D00112-001	MARQUEE LIGHTING PLATE



8-WAY JOYSTICK (63-00032-006)


FIGURE 8

ITEM	TATIO PART NO.	DESCRIPTION
1	63B00031-001	BALL & SHIFT
2	63A00033-001	MASK
3	63C00027-001	MOUNTING PLATE
4	62A00002-001	SHOCK MOUNT PLATE
5	63A00028-001	SWITCH PLATE
6	63A00030-001	ACTUATOR
7	61A00078-001	"L" BRACKET
8	63A00026-001	SWITCH SPACER
9	29B00016-002	LEAF SWITCH, SHORT
10	63A00029-001	SPACER
11	59B00020-017	"E" RING



CONTROL PANEL FIGURE 9


ITEM	TATIO PART NO.	DESCRIPTION
1	63B00024-001	PUSH BUTTON WHITE
2	42-00150-001	MOUNTING PLATE
3	42B00108-001	CLEAT, WOOD
4	61A00015-001	STRIKE HOOK
5	61-00216-001	METAL CONTROL PANEL
6	66-00015-001	CONTROL PANEL OVERLAY
7	29B00016-001	SWITCH LEAF
8	54A07001-008	NUT, STAMPED 5/8-11
9	63-00025-001	SWITCH SUPPORT
10	63-00156-004	PUSH BUTTON (SIDE PASS)
11	63-00156-005	PUSH BUTTON (FWD PASS)




DOOR ASSEMBLY SJC-3 FIGURE 10

ITEM	TAITO PART NUMBER	DESCRIPTION
1	61-00142-001	LOCK ROD ASSEMBLY
2	08-00140-001	GAME BOARD SET
3	08-00140-002	SOUND PCB
4	08-00140-003	CPU PCB
5	08-00140-004	VIDEO PCB
6	08-00141-001	FILTER PCB
7	07-00349-001	BRACKET PC BOARD
8 *	61A00014-001	"L" BRACKET
9	61-00111-001	BRACKET, LOCK ROD
10	61-00229-001	HINGE
11	42-00144-001	BACK DOOR
12	61-00356-001	GROUND PLATE
13 *	59-00016-001	SPACER (FILTER BOARD)

^{*} Item not shown on dwg.






COIN DOOR


FIGURE 11

ITEM	TAITO PART NO.	DESCRIPTION	REFERENCE
1	61-00270-001	DOOR FRAME	15-8039
2	61-00272-001	HINGE	30-9125
3	61-00273-001	TAITO NAME PLATE	15-8115
4	61-00277-001	SERVICE SWITCH BRACKET	15-8030
5	07-00242-001	LOCK 5/8" ASSEMBLY	34-1855
6	29-00037-001	SERVICE SWITCH	23-1339
7	61-00271-001	DOOR	15-8038
8	07-00243-001	LOCK CAM ASSEMBLY	55-2909
9	61-00278-001	LOCK CAM PLATE	55-2909
10	63-00124-001	COIN ENTRY SLOT	15-8074
11	63-00125-001	PUSH BUTTON COVER	15-8072
12	79-50034-001	.25 PRICE DECAL	15-8081
13	63-00126-001	PUSH BUTTON	15-8071
14	58-00007-001	COMPRESSION SPRING	30-7722
15	27-00008-001	LAMP #1815	21-1815
16	26-00019-001	LAMP SOCKET 25B4-L187	15-9419
17	61-00274-001	COIN CHUTE	15-8075
18	51-02002-006	#6-32 X 1/2 PR PH SCREW	
19	63-00127-001	REJECT LEVER	15-8084
20	63-00131-001	COIN ACCEPTOR RETAINER	15-8086
21	59-00020-025	1/4" E RING	30-0731
22	59-00055-001	PLASTIC COIN ACCEPTOR .25	31-4014
23	58-00008-001	EXTENSION SPRING	30-7372
24	29-00041-001	SWITCH	23-1347
25	61-00279-001	WIRE FORM (COIN SWITCH)	23-1348
26	63-00130-001	SWITCH COVER	15-8043
27	23-00003-001	COIN RETURN BOX	15-8091
28	63-00129-001	COIL BRACKET	15-8080
29		NOT USED	
30	51-02002-002	#6-32 X 1/4 PR PH SCREW	
31	61-00276-001	GUARD	15-8092
32	29-00036-001	SLAM SWITCH	15-1255
33	33-00002-001	COIN COUNTER 6VDC	31-4550
34	63-00128-001	COIN RETURN DOOR	15-8083
			-



COIN DOOR FIGURE 12


ITEM	TAITO PART NO.	DESCRIPTION	REFERENCE
1	61-00042-001	COIN DOOR ONLY (2 COIN)	404341
2	63-00015-001	COIN RETURN BUTTON	904591
3	79-50004-001	US ,25 PRICE DECAL	904703
4	63-00016-001	COIN RETURN BUTTON COVER	
5	07-00025-001	LOCK ASSEMBLY	904707-1
6	51-01051-003	SCREW #4 X 5/16 SL PH TYPE B	345-4-5
7	63-00011-001	COIN BUTTON HOUSING	904588
<u>,</u> 8	51-02051-002	SCREW #4-40 X 1/4 SL PH	325-4-4
9	63-00012-001	COIN RETURN BEZEL	904590
10	63-00013-001	COIN RETURN COVER	904599
11	61-00040-001	COIN DOOR FRAME 11 5/8 x 13 3/8 MOUNTS IN A 10 3/8 X 12 3/16 OPENING	
12	54-01005-001	HEX NUT 1/4-20	406-416
13	51A03003-113	CARRIAGE BOLT	904734
14	07-00026-001	LOCK CAM ASSEMBLY	404357



COIN DOOR FIGURE 13

TAITO PART NO.	DESCRIPTION	REFERENCE
07-00027-001	INNER PANEL W/LEVERS	404429 SUB ASSEMBLY
54-03013-001	NUT #8-32 400-8	
09-00017-001	CUSTOM HARNESS ASSEMBLY (SGL COIN)	
09-00017-002	CUSTOM HARNESS ASSEMBLY (DUAL COIN)	
61B00113-001	SERVICE SWITCH BRACKET	
29-00022-001	SERVICE SWITCH	
54-03011-001	NUT #4-40	904762
63-00014-001	SWITCH COVER	100-6-3
51-02052-001	NOT USED	
23-00001-001	NOT USED	
51-02052-001	SCREW #6-32 X 3/16 SS PH	100-4-12
59-00019-001	RETAINER	900651
28-00029-001	SILVER SWITCH FOR US .25	904710-1
29-00007-001	SWITCH	904845
61-00044-001	COIN CHUTE	904701
61-00045-001	COIN RETURN BOX	904598
61-00025-001	SWITCH & C.R.E.M. COIL BRACKET	404428
59-00018-001	.25 ACCEPTOR	5301-10
51-02051-006	SCREW 4-40 X 3/8 SS PH	110-4-6
27-00003-001	MINATURE BAYONET BASE LAMP 904717 * 26-00006-001 LAMP SOCKET	904717
27-00003-001	1815 LAMP 12V	
61-00048-001	COIN INLET CHUTE	904418
61-00047-001	RIGHT HALF OF COIN INLET CHUTE	904594
54-00001-001	"U" TYUPE FASTENER	904712
51-02051-006	SCREW 4-40 X 1/2 SS PH	116-4-8
29-00006-001	SLAM SWITCH ASSEMBLY	904704
33-00002-001	COIN METER	
63-00155-001	COIN REJECT LEVER	904583
	PART NO. 07-00027-001 54-03013-001 09-00017-002 61B00113-001 29-00022-001 54-03011-001 63-00014-001 51-02052-001 28-00029-001 29-00007-001 61-00044-001 61-00045-001 51-02051-006 27-00003-001 54-0001-001 51-00048-001 51-02051-006 27-00003-001 51-02051-006 29-00006-001 33-00002-001	PART NO. DESCRIPTION 07-00027-001 INNER PANEL W/LEVERS 54-03013-001 NUT #8-32 400-8 09-00017-001 CUSTOM HARNESS ASSEMBLY (SGL COIN) 09-00017-002 CUSTOM HARNESS ASSEMBLY (DUAL COIN) 61B00113-001 SERVICE SWITCH BRACKET 29-00022-001 SERVICE SWITCH S4-03011-001 NUT #4-40 63-00014-001 SWITCH COVER 51-02052-001 NOT USED 23-00001-001 NOT USED 51-02052-001 SCREW #6-32 X 3/16 SS PH 59-00019-001 RETAINER 28-00029-001 SILVER SWITCH FOR US .25 29-00007-001 SWITCH 61-00044-001 COIN CHUTE 61-00045-001 COIN RETURN BOX 61-00025-001 SWITCH & C.R.E.M. COIL BRACKET 59-00018-001 .25 ACCEPTOR 51-02051-006 SCREW 4-40 X 3/8 SS PH 27-00003-001 MINATURE BAYONET BASE LAMP 904717 * 26-00006-001 LAMP SOCKET 27-00003-001 RIGHT HALF OF COIN INLET CHUTE 61-00048-001 COIN INLET CHUTE 61-00048-001 COIN INLET CHUTE 61-00049-001 RIGHT HALF OF COIN INLET CHUTE 61-00049-001 COIN INLET CHUTE 54-00001-001 "U" TYUPE FASTENER 51-02051-006 SCREW 4-40 X 1/2 SS PH 29-00006-001 SLAM SWITCH ASSEMBLY 33-00002-001 COIN METER COIN MET

^{*} Item not shown on drawing.




CABINET ASSEMBLY REAR VIEW FIGURE 14

ITEM	TAITO PART NO.	DESCRIPTION
1	21-00003-001	SPEAKER
2	61B00027-001	SPEAKER GRILL
3	07M00042-001	A/C LINE CORD ASSEMBLY
4	61-00114-001	INTERLOCK BRACKET
*4A	59-00046-001	SWITCH BARRIER
5	29B00015-001	INTERLOCK SWITCH
6	07M00039-003	POWER SUPPLY ASSEMBLY
7	61C00054-001	CASH BOX LID
8	61D00060-001	CASH BOX
9	63R00010-001	CASH TRAY (ONLY)
10	63-00019-001	CASH TRAY SEPARATOR
11	61B00039-001	CASH TRAY HANDLE
12	42C00013-001	MONITOR SUPPORT CLEAT
13	61D00208-001	MOUNTING BRACKET
14	31-00013-001	19" COLOR MONITOR
15	04-00037-002	LOCK ASSEMBLY
16	44-00001-001	WHEEL ASSEMBLY
*17	07-00041-001	HEAT SINK ASSEMBLY
*18	08-00007-002	REGULATOR BOARD
*19	18-00003-001	TRANSFORMER

^{*} Item not shown on drawing.

CABINET ASSEMBLY FRONT VIEW FIGURE 15




CABINET ASSEMBLY FRONT VIEW FIGURE 15

ITEM	TAITO PART NUMBER	DESCRIPTION
1	07M00055-002	INCANDESCENT PANEL
2	63B00006-003	"U" CHANNEL BRACKET
3	47-00012-021	MARQUEE
4	61C00115-001	MARQUEE RETAINING BRACKET
5	47-00016-011	COVERGLASS
6	63-00053-001	SHROUD
7	07-00285-003	COIN DOOR
8	61B00113-001	SWITCH BRACKET
9	07-00118-001	SERVICE SWITCH ASSEMBLY
10	29-00022-001	SLIDE, CENTER RETURN SWITCH
11	59-00008-001	LATCHING CLAMP
12	63B00002-004	"T" MOLDING
13	29A00023-001	POWER ON/OFF SWITCH
*	09-00227-001	MAIN HARNESS CABLE
*	09-00043-001	SPEAKER CABLE
14	41-00024-005	FINISHED CABINET
15	07-00347-001	CONTROL PANEL ASSEMBLY
16	27-00006-001	#47 BULB
17	26-00008-001	LAMP CLIP-ON MINI BAY

^{*} Item not shown on drawing.

POWER SUPPLY COMPONENT LAYOUT FIGURE 16



POWER SUPPLY BOARD FIGURE 16

SYM	TAITO PART NO.	DESCRIPTION
R1	11-00001-102	RES, 1.0K 1/4W 5%
R2		RES, 5.1K 1/4W 5%
R3	11-00001-183	RES, 18K 1/4W 5%
R4	11-00001-224	RES, 220K 1/4W 5%
R5	11-00001-472	RES, 4.7K 1/4W 5%
R6	11-00001-222	RES, 2.2K 1/4W 5%
R7	11-10001-101	RES, 100 1/4W 5%
R8	11-00001-102	RES, 10K 1/4W 5%
R9	11-00001-472	RES, 4.7K 1/4W 5%
R10	11-10001-101	RES, 100 1/2W 5%
R11	11-30001-015	RES, .15 4W 5%
R12	11-30001-015	RES, .15 4W 5%
R13	11-00001-472	RES, 4.7K 1/4W 5%
R14	11-00001-222	RES, 2.2K 1/4W 5%
R15	11-00001-222	RES, 2.2K 1/4W 5%
R16	11-60001-252	RES, VAR 2.5K 1/4W 20%
R17	11-00001-222	RES, 2.2K 1/4W 5%
R18		RES, VAR 1.0K 1/4W 20%
R19		RES, 510 1/4W 5%
R20		RES, 47 1/2W 5%
R21		RES, 1.6K 1/4W 5%
R22		RES, 10K 1/4W 5%
R23		RES, 4.7K 1/4W 34
R24	11-00001-222	RES, 2.2K 1/4W 5%
R25	11-60001-102	RES, VAR 1.0K 1/4W 5%
R26		RES, 4.7K 1/4W 5%
R27		RES, 2.2K 1/4W 5%
R28		RES, VAR 2.5K 1/4W 20%
R29		RES, 4.7K 1/4W 5%
R30		RES, 1.2K 1/4W 5%
R31		RES, 47 1/4W 5%
R32	}	RES, .15 4W 5%
R33	11-00001-222	RES, 2.2K /4W 5%
R34	11-00001-122	RES, 1.2K 1/4W 5%
R35	11-00001-511	RES, 510 1/4W 5%
R36	11-00001-222	RES, 2.2K 1/4W 5%
R37	11-00001-104	RES, 100K 1/4W 5%
R38	11-00001-103	RES, 10K 1/4W 5%
R39	11-00001-224	RES, 220K 1/4W 5%
C1	12-30001-225	CAP, TANT 2.2uf 25V
C2	12-10004-103	CAP, CER .01uf 50V
C3	12-10004-103	CAP, CER .01uf 50V
C4	12-30001-105	
C5	12-10001-102	CAP, .001uf 50V
C6	12-30001-106	CAP, TANT 10uf 16V
C7	12-20003-509	CAP, ELECTRO 50,000uf


TAITO PART NO.	DESCRIPTION
12-30001-105	CAP, TANT 1uf 35V
	CAP, ELECTRO 20,000uf 30V
12-10001-332	CAP, CER .0033uf 50V
12-30001-476	CAP, TANT 47uf 15V
12-30001-105	CAP, TANT 1.uf 35V 50V
12-10004-103	CAP, CER .01uf 50V
	CAP, .001uf 50V
12-30001-476	CAP, TANT 47uf 15V
12-20002-108	CAP, ELECTRO 1,000uf 30V
12-30001-225	CAP, TANT 2.2uf 25V
12-30001-225	CAP, TANT 2.2uf 25V
	CAP, TANT 1uf 35V
24-00003-010	10A FUSE
24-00003-010	10A FUSE
24-00003-003	FUSE, 2A
24-00003-004	FUSE, 4A
24-00003-004	FUSE, 4A
13-00100-025	DIODE BRIDGE 25A, 100V
	DIODE BRIDGE 12A, 100V
13-00100-002	DIODE BRIDGE 2A, 100V
13-14002-001	DIODE IN4002
13-14002-001	DIODE IN4002
	DIODE ZENER IN752
13-14002-001	DIODE IN4002
	DIODE ZENER IN964
13-14002-001	DIODE IN4002
	DIODE IN4002
	DIODE IN4002
	<u> </u>
	
	
1	VOLTAGE REGULATOR 723
15-50723-001	VOLTAGE REGULATOR 723
	VOLTAGE REGULATOR 7912
	VOLTAGE REGULATOR 79L05
ļ	TRANSISTOR 2N2905
	TRANSISTOR 2N2905
	
	
	PART NO. 12-30001-105 12-20003-209 12-10001-332 12-30001-476 12-30001-105 12-10004-103 12-10001-102 12-30001-476 12-30001-225 12-30001-225 12-30001-225 12-30001-005 24-00003-010 24-00003-010 24-00003-004 24-00003-004 13-00100-025 13-00100-025 13-14002-001

POWER SUPPLY BOARD FIGURE 16

SYM	TAITO PART NO.	DESCRIPTION
Q5	14-23055-001	TRANSISTOR 2N3055
Q6	14-22905-001	TRANSISTOR 2N2905
Q7	14-20030-001	TRANSISTOR TIP-30A
Q8	14-26401-001	SCR 2N6401
Q9	14-26401-001	SCR 2N6401
J1	25-00022-006	CONNECTOR, 6PIN
J2	25-00022-008	CONNECTOR, 8PIN
J3	25-00002-014	CONNECTOR, 14PIN
J4	25-00002-014	CONNECTOR, 14PIN
*	24-10001-001	FUSECLIPS
*	30-00220-002	HEAT SINK DUAL TO-220
*	30-00003-001	HEAT SINK SINGLE TO-3
*	30-00005-001	HEATSINK 3" FIN
*	51-02002-011	BOLT
*	54-02002-001	NUT
D13	13-16276-001	TRANSORB IN6276
D14	13-16281-001	TRANSORB IN6281
D17	13-16267-001	TRANSORB IN6267
*BR1	32-00004-001	PCB REGULATOR
*	13-00100-025	DIODE BRIDGE 25A, 100V
*	30-00007-001	HEAT SINK FOR BR1


^{*} Item not shown on drawing.

POWER SUPPLY SCHEMATIC 1 of 1 FIGURE 17





FILTER BOARD FIGURE 20

TAITO PART NO.	DESCRIPTION	QUANITY
12-10001-471	CAP, 470PF ± 10% AXIAL LEAD	36
17-00001-001	FERRITE BEAD ASSEMBLY	18
25-00002-014	CONNECTOR 14P	9
25-00002-005	CONNECTOR 5P	2
63B00068-001	STAND OFF	6
17-10001-001	10 UH INDUCTOR	5
	PART NO. 12-10001-471 17-00001-001 25-00002-014 25-00002-005 63B00068-001	PART NO. DESCRIPTION 12-10001-471 CAP, 470PF ± 10% AXIAL LEAD 17-00001-001 FERRITE BEAD ASSEMBLY 25-00002-014 CONNECTOR 14P 25-00002-005 CONNECTOR 5P 63B00068-001 STAND 0FF





TOP PCB (M52-Sound) FIGURE 19







CENTER PCB (M58-A-A) FIGURE 21






CENTER PCB (M58-A-A) 2 of 4 FIGURE 22







CENTER PCB (M58-A-A) 4 of 4 FIGURE 22





BOTTOM PCB (M58-B-A) FIGURE 23




REVISIONS








BOTTOM PCB (M58-B-A) 4 of 5 FIGURE 24




BOTTOM PCB (M58-B-A) 5 of 5 FIGURE 24





WIRING DIAGRAM

TYPICAL IS PLACES



G DIAGRAM







1256 Estes Avenue, Elk Grove Village, IL 60007 Telephone (312) 981-1000 Telex 25-3290